



INSTRUCTION MANUAL
Commercial Banana Slicer

Dear Customer,

We are glad to welcome you to the maxel family.

At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money. More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

Directions to Use:

- ❖ Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- ❖ The order to be followed for using the machine is as follows.
 - * Clean the machine with dry cloth and check if throw disc is placed properly.
 - * Loosen the tightening knob of motor placed on top, turn it in CCW direction when seen from top. Now open the top door.
 - * Place the blade above the throw disc, rotate it clockwise for locking. After placing, close the top door and lock it. Now turn the motor in CW direction when seen from top, push it downwards in such a way that the tip of the cleaning bristles is just above the blade, tighten the knob.
 - * Choose the input port out of the two, depending upon the size and shape of the Tapioca and use the same.
 - * Switch ON the machine and process the Bananas.
 - * Switch OFF once the batch is over.

- * After the process is over, open the top door by unlocking it as said in step 2, then rotate the blades slightly in CCW direction and lift it to take them out.
- * Repeat the previous 6 steps for further batches.
- * Clean the blade with water and machine with wet and dry cloth.
- * Lock the machine at the end after every use.

Do's & Don'ts:

- ❖ Keep the machine on a flat & non-slippery surface.
- ❖ Keep the machine out of the reach of the children.
- ❖ Ensure all screws are tightened in all blades before every use.
- ❖ Ensure safe handling of blades as they are extremely sharp.
- ❖ Do not use the machine before reading this manual.
- ❖ Do not run the machine empty for more than 10 seconds.
- ❖ Do not try to wash the machine directly with hoses. Use wet or dry cloth to wipe it.
- ❖ Do not insert your hands either inside the outlet area or inside the top vent when the machine is running. This will cause severe injury.
- ❖ Do not run the machine without proper earthing.
- ❖ Do not feed the machine with bananas, before turning ON the machine.

- ❖ Do not overload the machine beyond its capacity.
- ❖ Do not use any third-party accessory in the machine.

Caution : In case of overriding of the above-mentioned instructions, warranty becomes void.



Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**