



**INSTRUCTION MANUAL**  
**Commercial Conventional Better Mixer**

## **Dear Customer,**

We are glad to welcome you to the maxel family.

At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money. More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

## **Directions to Use:**

- v Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- v In case of a three-phase machine, connect the wire to a three-phase power source using appropriate plug. Power ON the machine. In case, the machine is not running in CW direction seen from top, interchange any 2 wires. In case of single phase, machine is ready for plug and play.
- v Before the first actual usage, wash the drum with water twice.
- v The order to be followed for blending is as follows.
  - k Make sure that machine is in semi tilted position & locked at that position.
  - k Clean the drum with wet cloth. Clean the blender with water by taking it out.
  - k Switch ON the machine
  - k Add rice batter and urad dhal gradually
  - k After attaining required consistency in batter, switch OFF the machine
  - k Take the batter out by tilting the machine. After batter collection is over, tilt back the machine to its standing position.

- k Wash with water and take out the same
  - k Clean all parts of the machine with wet and dry cloth
- v Gear oil should be changed once in 6 months to ensure smooth running of gearbox.

### **Do's & Don'ts:**

- v Do not spill water inside the box through the gap between drum and box, as it will directly damage the gearbox and motor.
- v Do not run the machine empty.
- v Do not use the machine for the blending of substance other than rice and urad dhal batter.
- v Do not try to wash the machine directly with hoses.
- v Do not run the machine for more than 8 months without the change of gear oil.
- v Do not place the machine on a slippery / sloping floor.
- v Do not feed the machine before switching it ON.
- v Do not put the hands inside the drum while running.
- v Do not run the machine without proper earthing.
- v In case of power failure, please take some of the batter out before switching it ON the next time. Skipping this might load the motor heavily.
- v Do not run the machine without locking the top arm that holds the blender in place.

- v Keep the machine out of the reach of the children.
- v Do not use the machine before reading this manual.
- v Do not over load the machine beyond its capacity.
- v Do not use only third-party accessory in the machine.

**Caution : In case of overriding of the above-mentioned instructions, warranty becomes void.**



Manufactured by:

**Lakshmi Engineering Products**

No.31, Puliakulam Main Road,  
Coimbatore - 641045, Tamil Nadu, India.

Website : [www.maxelplus.com](http://www.maxelplus.com)

Email : [customercare@maxelplus.com](mailto:customercare@maxelplus.com)

Customer Care Number : **+91 (422) 4351519**