



INSTRUCTION MANUAL

Commercial Coconut Scrapper

Dear Customer,


We are glad to welcome you to the maxel family. At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money.

More than making your job effortless, we are delighted that we are assisting you in amaking the tastiest and healthiest foods every day!

Directions to Use:

- Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- The order to be followed for kneading is as follows.
 - Clean the machine with dry cloth.
 - After plugging in the power chord in power socket, switch ON the machine.
 - Keep one half of the coconut against the scrapper by holding its back.
 - Scrap the sides of the coconut first and then the centre.
 - Repeat the previous 2 steps for further batches.
 - After the process is over, switch OFF the machine.
 - Clean the machine with wet and dry cloth.

Do's & Don'ts

- Keep the machine on a flat & non-slippery surface.
 - Keep the machine out of the reach of the children.
 - Ensure the machine is always used by experienced users.
 - Do not use the machine before reading this manual.
 - Do not run the machine empty for more than 10 seconds.
 - Do not try to wash the machine directly with hoses. Use wet or dry cloth to wipe it.
 - Do not touch the scrapper with bare hands when the machine is running, as the same will badly hurt.
 - Do not run the machine without proper earthing.
 - Do not run the machine continuously for more than 1 hour. A break of 5 minutes is sufficient for the next batch.
 - Do not use any third party accessory in the machine.
- 



Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**