



INSTRUCTION MANUAL
Heavy Duty Mixer

Dear Customer,

We are glad to welcome you to the maxel family. At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money.


More than making your job effortless, we are delighted that we are assisting you in amaking the tastiest and healthiest foods every day!

Directions to Use:

- Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- The order to be followed for using the machine is as follows.
 - Clean the machine with dry cloth.
 - Fix the blade in place and tight it in CCW direction completely.
 - Feed the materials to be ground, add some water if needed.
 - Close the lid and make sure the machine is locked for its standing position.
 - Switch ON the machine and leave it for 3-5 minutes or for your preferred time.
 - If water has to be added in between, please switch OFF the machine, open the lid and add the same.

- After the process is over, switch OFF the machine, open the lid, tilt and collect the ground materials.
- Repeat the previous 5 steps for further batches.
- Rinse the drum, then wipe the machine with wet and dry cloth.

Do's & Don'ts

- Keep the machine in a flat & non-slippery surface.
 - Keep the machine out of the reach of the children.
 - Do not operate this machine before reading this manual.
 - Do not open the lid when the machine is running.
 - Do not run the machine empty for more than 10 seconds.
 - Do not run the machine without a proper earthing.
 - Do not overload the machine beyond its capacity of 5 kg.
 - Do not run the machine with open lids.
 - Do not use any third-party accessory.
 - Do not wash the machine directly with hoses. Please wipe it with wet and dry cloth.
- 



Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**