



INSTRUCTION MANUAL
Commercial Instant Grinder

Dear Customer,

We are glad to welcome you to the maxel family. At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money.

More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

Directions to Use:

- Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- The order to be followed for using the machine is as follows.
 - Clean the machine with dry cloth.
 - Fix the blade in position and lock the outer case by closing it and tightening the 4 knobs provided.
 - After connecting the water inlet to the tap line provided at the top, open the tap to the desired level.
 - Turn ON the machine and slowly feed the rice.
 - Obtain the required consistency of batter by simultaneously adjusting the wheel in front by rotating it, and feeding the rice and water in appropriate levels.
 - After the process is over, close the input water valve and open the cleaning valve and allow the water to flush through blades to wash it away for few seconds.

- Now open the case and clean all the inside parts completely after every use.
- Directions to change/reverse the blade:
- Remove the 4 black plastic knobs in the front face.
- Now remove the 4 Helen screws on the blade, take out the blade.
- For reversing the same blade, turn it around. Else use a new blade.
- Fix it, tight the 4 Helen screws.
- Repeat the same procedure for the other blade also.

•Do's & Don'ts

- Keep the machine on a flat & non-slippery surface.
- Keep the machine out of the reach of the children.
- Ensure case and spring nuts are tightened completely.
- Ensure safe handling for blades as they are extremely sharp.
- Do not use the machine before reading this manual.
- Do not run the machine empty for more than 5 seconds.
- Do not try to wash the machine directly with hoses. Use wet or dry cloth to wipe it.
- Do not insert your hands either inside the outlet area or inside the top vent when the machine is running. This will cause severe injury.
- Do not run the machine without proper earthing.
- Do not open the case while the machine is running.
- Do not feed rice without water.
- Do not overload the machine beyond its capacity.

- Do not use any third-party accessory in the machine.
- Do not tight the rotating wheel in front fully, as it will damage blades and cause heavy noise.



Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**