



INSTRUCTION MANUAL

Commercial Oil Dryer

Dear Customer,

We are glad to welcome you to the maxel family.

At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money. More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

Directions to Use:

- ❖ Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- ❖ In case of a three-phase machine, connect the wire to a three-phase power source using appropriate plug. Power ON the machine. In case, the machine is not running in CW direction seen from top, interchange any 2 wires. In case of single phase, machine is electrically ready for plug and play.
- ❖ The order to be followed for peeling is as follows.
 - * Clean the inside of the drum with pressurised water.
 - * Feed the input in the dryer vessel a little below the capacity of the machine in order to ensure durability.
 - * Set the timer for required number of minutes and then turn on the machine.
 - * Now wait for 2-5 minutes and periodically check for consistency of oil content.
 - * Once the drying process is over remove the dryer vessel and collect the material.
 - * Repeat the previous 4 steps for further batches. Turn OFF the machine after use.
 - * Clean the inside of the drum with water. Use wet and dry clothes to wipe the outside of the machine.

Do's & Don'ts:

- ❖ Keep the machine on a flat and non-slippery surface.
- ❖ Keep the machine out of the reach of the children.
- ❖ Make sure there is proper draining for the machine, failing which leads to accumulation of water/oil inside the drum.
- ❖ Do not use any acidic substance to clean the dried oil.
- ❖ Do not use any corrosive products on the machine.
- ❖ Do not use the machine before reading this manual.
- ❖ Do not overload the machine beyond its capacity.
- ❖ Do not use any third-party accessory in the machine.
- ❖ Do not run the machine empty for more than 10 seconds.
- ❖ Do not put the hands inside the drum while running.
- ❖ Do not run the machine without proper earthing.
- ❖ Do not turn the timer knob counter clockwise direction.

Caution : In case of overriding of the above-mentioned instructions, warranty becomes void.





Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**