



**INSTRUCTION MANUAL**  
**Commercial Variety Rice Mixer**

## **Dear Customer,**

We are glad to welcome you to the maxel family.

At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money. More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

## **Directions to Use:**

- ❖ Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- ❖ In case of a three-phase machine, connect the wire to a three-phase power source using appropriate plug. Power ON the machine. In case, the machine is not running in CW direction seen from front, interchange any 2 wires. In case of single phase, machine is electrically ready for plug and play.
- ❖ The order to be followed for using the machine is as follows.
  - \* Clean the machine with dry cloth.
  - \* Tilt the machine to the 45° position and lock it with the tilt lock provided.
  - \* Feed the machine with the items to be mixed.
  - \* Switch ON the machine and wait till the items get mixed up properly.
  - \* Now switch OFF the machine, tilt it to the 110° position and lock it with the tilt lock provided.

- \* Take out the mixed items with a collecting vessel kept below the drum.
- \* Repeat the previous 5 steps for further batches.

### **Do's & Don'ts:**

- ❖ Keep the machine in a flat & non-slippery surface.
- ❖ Keep the machine out of the reach of the children.
- ❖ Do not use the machine before reading this manual.
- ❖ Do not run the machine empty for more than 10 seconds.
- ❖ Do not operate the machine for more than 8 months without the change of gear oil.
- ❖ Do not try to wash the machine directly with hoses. Use wet or dry cloth to wipe it.
- ❖ Do not insert your hands either inside the drum when the machine is running. This will cause severe injury.
- ❖ Do not run the machine without proper earthing.
- ❖ Do not run the machine without locking the side lock/tilt lock.
- ❖ Do not overload the machine beyond its capacity.
- ❖ Do not use any third-party accessory in the machine.
- ❖ Do not spill water inside the box through the gap between drum and box, as it will directly damage the gearbox and motor.
- ❖ Do not use the machine for mixing any other items except rice as it is specifically designed for that purpose.

- ❖ In case of power failure, please take some of the rice out before switching it ON the next time. Skipping this might load the motor heavily.
- ❖ Clean the inside of the drum after daily usage of the machine with wet and dry cloth.

**Caution : In case of overriding of the above-mentioned instructions, warranty becomes void.**



Manufactured by:

**Lakshmi Engineering Products**

No.31, Puliakulam Main Road,  
Coimbatore - 641045, Tamil Nadu, India.

Website : [www.maxelplus.com](http://www.maxelplus.com)

Email : [customercare@maxelplus.com](mailto:customercare@maxelplus.com)

Customer Care Number : **+91 (422) 4351519**