



INSTRUCTION MANUAL
Commercial Curd Churning Machine

Dear Customer,

We are glad to welcome you to the maxel family.

At maxel, we make products with precision and at most quality, ensuring that our customers are deriving complete value for their money. More than making your job effortless, we are delighted that we are assisting you in making the tastiest and healthiest foods every day!

Directions to Use:

- ❖ Upon un-wrapping, remove the warranty card from the machine and keep it safe.
- ❖ The order to be followed for using the machine is as follows.
 - * Clean the machine with dry cloth.
 - * Plug the machine to an appropriate socket.
 - * Make sure the drain valve at the bottom is closed.
 - * Open the lid, lift and hang it with chain provided.
 - * Pour in the curd and required water. Close the lid tightly.
 - * Switch ON the machine by turning the black knob. Set the required timing and start the churning operation by pressing GREEN button.
 - * If you want to stop the machine in between the churning operation, press the RED button and then open the lid.
 - * Else, Once the process is over, open the lid and collect the butter completely in a vessel.
 - * With a valve below the drain pipe, open the drain valve and collect the butter milk.

- * Repeat the previous 7 steps for further batches.
- * Clean the machine with wet and dry cloth.

Do's & Don'ts:

- ❖ Keep the machine in a flat & non-slippery surface.
- ❖ Keep the machine out of the reach of the children.
- ❖ Do not use the machine before reading this manual.
- ❖ Do not run the machine empty for more than 10 seconds.
- ❖ Do not try to wash the machine directly with hoses. Use wet or dry cloth to wipe it.
- ❖ Do not run the machine without proper earthing.
- ❖ Do not overload the machine beyond its capacity.
- ❖ Do not use any third-party accessory in the machine.
- ❖ Do not open the lid when the machine is in operation.
- ❖ Do not try to leave your hands inside the drum when the machine is in operation as it will badly hurt the hands.
- ❖ Clean the inside of the drum with cleaning liquid after every usage of the machine.

Caution : In case of overriding of the above-mentioned instructions, warranty becomes void.



Manufactured by:

Lakshmi Engineering Products

No.31, Puliakulam Main Road,
Coimbatore - 641045, Tamil Nadu, India.

Website : www.maxelplus.com

Email : customercare@maxelplus.com

Customer Care Number : **+91 (422) 4351519**